



1. Wall preparation

- a. Ensure the wall surface is clean, dry, sound, smooth and absorbant to paste.
- b. Best results will be obtained if the wall surface is mirror smooth. Where necessary fill holes with fine filler and use sand paper to remove all lumps. Surface imperfections may be visible after the wallcovering is installed.
- c. Switch off the supply of electricity to sockets and light switches as a precaution.
- d. Switch off radiators during installation. Removal of radiators will aid installation if in the immediate area but not essential.

2. Tools Required

- a. A felt or sponge roller for paste application
- b. Scissors or Sharp blade knife
- c. Straight edge
- d. Soft wallpaper brush
- e. Soft cloth or sponge

3. MS Lite wallcovering Installation

- a. Allow material to adjust to room temperature before hanging
- b. Take care not to scratch surface with hanging tools especially if pre-printed

4. MS Lite Hanging Instructions

- a. Cut MS Lite into required lengths
- b. Pour paste contents into paste tray
- c. Paste the wall. Soaking is not necessary
- d. Apply the MS Lite lengths, edge to edge, vertically or horizontally
- e. Use a soft wallpaper brush to remove bubbles and creases
- f. Use a straight edge and trimming knife or scissors at corners
- g. Remove any excess paste with a damp sponge
- h. Leave to dry thoroughly (24 hrs)
- i. The wall is now ready to hold magnets!
- j.

5. MS Plus Lite Printing options

MS Lite is designed to be digitally printed.

- a. Use solvent or UV inks
- b. Ensure the printer can accept width of material
- c. Do not use water-based inks

