



1. Wall preparation

- a. Ensure the wall surface is clean, dry, sound, smooth and absorbant to paste.
- b. Best results will be obtained if the wall surface is mirror smooth. Where necessary fill holes with fine filler and use sand paper to remove all lumps. Surface imperfections may be visible after the liner is installed.
- c. Switch off the supply of electricity to sockets and light switches as a precaution.
- d. Switch off radiators during installation. Removal of radiators will aid installation if in the immediate area but not essential.

2. Tools Required

- a. A felt or sponge roller for paste application
- b. Scissors or Sharp blade knife
- c. Straight edge
- d. Soft wallpaper brush
- e. Soft cloth or sponge

3. MS Plus Liner / MS Plus Dry Erase Installation

IMPORTANT:

MS Plus Liner: For best adhesion, apply the MS Plus Liner with its matt side facing the wall (shiny side facing out).

MS Plus Dry Erase: Apply to wall, white side facing out.

4. MS Plus Hanging Instructions

- a. Cut MS Plus into required lengths
- b. Pour paste contents into paste tray
- c. Paste the wall. Soaking is not necessary
- d. Apply the MS Plus lengths, edge to edge, vertically or horizontally
- e. Use a soft wallpaper brush to remove bubbles and creases
- f. Use a straight edge and trimming knife or scissors at corners
- g. Remove any excess paste with a damp sponge
- h. Leave to dry thoroughly (24 hrs)
- i. The wall is now ready to hold magnets!

5. MS Plus Liner Finishing options

Once the MS Plus Liner is on the wall, you may choose to give it a decorative finish.

Wallpaper: Overhang the MS Plus Liner with your favourite wallpaper

- a. Ensure the MS Plus Lined wall is thoroughly dry
- b. Paste the MS Plus Lined wall
- c. Apply the chosen wallpaper over the MS Plus Liner
- d. Use a soft wallpaper brush to remove bubbles and creases
- e. Use a straight edge and trimming knife or scissors at corners
- f. Remove any excess paste with a damp sponge
- g. Leave to dry thoroughly before applying magnets

Paint: Over paint the MS Plus Liner in your colour of choice (using our recommended Wallrock 55 Fibreliner)

- a. Ensure the MS Plus Lined wall is thoroughly dry
- b. Paste the MS Plus Lined wall
- c. Apply 'Wallrock 55 Fibreliner' over the MS Plus Liner
- d. Use a soft wallpaper brush to remove bubbles and creases
- e. Use a straight edge and trimming knife or scissors at corners
- f. Remove any excess paste with a damp sponge
- g. Leave to dry thoroughly before applying emulsion paint

Important: MS Plus liner is a non-porous material. This means that standard pulp lining papers and wallpapers when applied on top can shrink when drying. For this reason, we recommend overhanging with non-woven wallpapers which do not shrink.

Stockist: Mav Wallrock 55 Fibreliner <http://www.transtools.co.uk>

PLEASE NOTE: MAGSCAPES LIMITED WILL NOT BE HELD RESPONSIBLE FOR ANY BADLY HUNG OR FAULTY MATERIAL AFTER HANGING.